



MOTO™ WX161/WX181

Getting Started Guide

accessories & more

www.motorola.com

68014173001
CJB2160ALAAA

congratulations


Congratulations on your purchase of the stylish Motorola WX161/WX181 phone. Whether you're a talker, a texter or just love listening to the radio on the move, the WX161/WX181 does it all.

We've crammed all the main features of your phone into this handy guide—you can even take the guide with you.


If you'd like even more information about how to use your new WX161/WX181, visit www.motorola.com/support. So, let's go.

Note: Your phone may not look exactly like the image in this manual. However, all key locations, sequences and functions are the same.

let's go




your phone



calls

make & answer calls



end calls



emergency calls

To call an emergency number, enter the emergency number and press **□**. Your service provider programmes emergency phone numbers (such as 999 or 112) that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your phone's pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental or interference issues.

messages

send messages

- 1 Press **•** > Messages > Create SMS.
- 2 Enter your message.

Tip: Press Options > Input mode to switch text entry modes. Press **#** to switch capitalisation modes. Press **#** to enter a space. Press **0** to change language.

- 3 Press **•**.
- 4 Enter a number and press **•** or press **•** and scroll to a contact. Press **•** to select a contact.
- 5 Press **•** to send.

read messages

When you receive a message, you will see **1 new message** on your screen. Press **•** > Read to open the message. You can reply to the message by pressing Options > Reply.

tips & tricks

ring style

To quickly switch your ring style, press and hold **#** from the home screen.

keypad lock

To quickly lock your keypad, press and hold **#** from the home screen. Press and hold **#**, then **Ok** to unlock.

torch on

To quickly turn on your torch, press and hold **5** from the home screen.

voicemail

Press and hold **1**. If your voicemail number is pre-set, you will connect.

recent calls

To see your dialled and received calls, press **□** from the home screen.

radio

listen to the radio

- 1 Plug a mini-USB headset into your phone.

Note: The FM radio works only when the headset is plugged in.

- 2 Press **•** > FM radio from the home screen.

To tune in a station, press **•** left or right. To adjust the volume, press **•** up or down. To turn off the radio, press Options > Turn off.

store favourite stations

When listening to a station, press Options > Save channel > Ok and answer yes to the prompt(s). Then press Add to store it.

Press Options > Channel list to see your stored stations. Press keys **1** to **3** **0** to select a stored station.

main menu

Games

FM radio

Tools

- Torch
- Organiser
- Stopwatch
- Alarm
- Calculator
- Converter
- My shortcuts

Phonebook

Call register

- Call memory
- My numbers
- Billing
- Call settings
- Call control

Profiles

- General
- Meeting
- Outdoor
- Indoor
- Headset
- Silent

Services *

- Display
- Clock
- Keys
- Dictionary
- More settings

This is a standard main menu layout. Your phone's menu may be a little different.

* Network dependent



68014173001

CJB2160ALAAA




basics

turn it on & off



menu navigation



Press the centre key **•** to open the main menu.

Press the navigation key **•** up, down, right or left to highlight a menu option. Press **•** to select the highlighted option. Press Options to display the menu options.



68014173001

CJB2160ALAAA



contacts

save contacts

- 1 Enter the number on the home screen and press Save.
- 2 Press Edit and enter name.
- 3 Press Options > Done when you've finished.
- 4 Press Done to save.

call contacts

- 1 Press **•** > Phonebook.
- 2 Scroll through the list to highlight the contact's number.
- 3 Press **□**.



68014173001

CJB2160ALAAA



personalise

set your wallpaper

Change the wallpaper to one that makes you smile.

Find it: **•** > Settings > Display > Wallpaper

set time & date

Set the time & date shown on your home screen.

Find it: **•** > Settings > Clock > Time & date

set ringtone and volume

Play it loud or keep it quiet, you choose.

Find it: **•** > Profiles

Choose from the pre-programmed profiles, including, General, Meeting (vibrate), Outdoor, Indoor, Headset and Silent. Press Options to edit a profile.



68014173001

CJB2160ALAAA



tools

create shortcuts

Choose the features you want to access with a single key press from the home screen—really useful stuff:

Find it: **•** > Tools > My shortcuts > Add > Functions > Keys

phone lock

Lock your phone to prevent others from using it.

Find it: **•** > Settings > More settings > Security > Activate phone code > press On > enter code

You will need to enter the code when you turn the phone on.

hands-free

During a call, press Hands-free to use the speakerphone.



68014173001

CJB2160ALAAA



text entry

To change modes when you are entering text, press Options > Input mode:


entry modes

Sabc	Smart (predictive text) predicts the word you want, with just one key press per letter. For example, to enter Home, press 4 6 6 3 . If the prediction is not correct, press • up or down to show other options.
Multitap	Multitap lets you press a key one or more times to cycle through the letters and numbers of that key.
123	Add numbers mode enters numbers only.

To enter symbols select Insert symbols.

home screen

The home screen is displayed when you turn on the phone. Status indicators can appear across the top of the home screen:



Note: Your phone's home screen may be different from the one shown.

Safety, regulatory & legal

Battery use & safety

Important: Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- Don't disassemble, crush, puncture, shred or otherwise attempt to change the form of your battery.
- Don't let the phone or battery come in contact with water. Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your service provider or contact Motorola, even if they appear to be working properly.*
- Don't allow the battery to touch metal objects. If metal objects, such as jewellery, stay in prolonged contact with the battery contact points, the battery could become very hot.
- Don't place your battery near a heat source. Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak or malfunction. Therefore:
- Do not dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
- Avoid leaving your phone in your car in high temperatures.*

DOS

- Do avoid dropping the battery or phone. Dropping these items, especially on a hard surface, can potentially cause damage.*
- Do contact your service provider or Motorola if your phone or battery has been damaged by being dropped or by high temperatures.

* Note: If the product guide expressly states that your phone is designed to resist damage from exposure to certain rugged conditions, such as water immersion, rain, dust, high and low temperatures, shock or other conditions, do not exceed the stated limits and ensure the stated precautions are taken.

Always make sure that the battery compartment is closed and secure to avoid direct exposure of the battery to any of these conditions.

Important: Use Motorola Original products for quality assurance and safeguards.

To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a "Motorola Original" hologram.

Motorola recommends that you always use Motorola-branded batteries and chargers. Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as

Invalid battery or Unable to charge, take the following steps:

- Remove the battery and inspect it to confirm that it has a "Motorola Original" hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and try charging it again;
- If the message remains, contact a Motorola authorised service centre.

Important: Motorola's warranty does not cover damage to the phone caused by non-Motorola batteries and/or chargers.

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage or other hazard.

Proper and safe battery disposal and recycling: Proper battery disposal is not only important for safety, it also benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:

- www.motorola.com/recycling
- www.rsrc.org/call2recycle/ (in English only)

Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling centre or national recycling organisations for more information on how to dispose of batteries.

Warning: Never dispose of batteries in a fire because they may explode.

Battery charging

Notes for charging your phone's battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.

Specific absorption rate (ICNIRP)

Your model wireless phone meets international guidelines for exposure to radio waves.

Safety & general information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.

Exposure to radio frequency (RF) energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate using your mobile device, the system handling your call controls the power level at which your mobile device transmits. The ICNIRP SAR limit for mobile devices used by the general public is 2 watts per kilogram (W/kg), and the highest SAR value for this mobile device when tested at the ear is 0.859 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this guide. In this case, the highest tested SAR value is 0.489 W/kg. The tests are carried out in accordance with international guidelines for testing. The SAR information includes the Motorola testing protocol, assessment procedure and measurement uncertainty range for this product.

Operational precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

Product operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimetres (1 inch) from your body when transmitting.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF energy interference/compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow instructions to avoid interference problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an aeroplane mode or similar feature, consult airline staff about using it in-flight.

Implantable medical devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your doctor before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimetres (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimise the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your health care provider.

Driving precautions

Using a mobile device while driving may cause distraction. End a call if you can't concentrate on driving. Enter information about your destination and route prior to your drive. Do not enter data or engage in text messaging while driving. Keep your eyes on the road while driving. Listen to the audible turn-by-turn directions, if available.

Also, using a mobile device or accessory may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. Responsible driving practices can be found at www.motorola.com/callsmart (in English only).

Operational warnings

Obey all posted signs when using mobile devices in public areas.

Potentially explosive atmospheres

Areas with potentially explosive atmospheres are often, but not always, posted and can include fuelling areas, such as below decks on boats, fuel or chemical transfer or storage facilities or areas where the air contains chemicals or particles, such as grain dust or metal powders.

When you are in such an area, turn off your mobile device and do not remove, install or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Content copyright

The unauthorised copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright or materials which you are authorised or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.

Symbol key

Your battery, charger or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not dispose of your battery or mobile device with normal household waste.
	Do not let your battery, charger or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

FCC notice to users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use & care

To care for your Motorola phone, please keep it away from:

Liquids of any kind
Don't expose your phone to water, rain, extreme humidity, sweat or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or drier, as this may damage the phone.

Extreme heat or cold
Avoid temperatures below 0°C/32°F or above 45°C/113°F.

Microwaves
Don't try to dry your phone in a microwave oven.

Dust and dirt
Don't expose your phone to dust, dirt, sand, food or other inappropriate materials.

Cleaning solutions
To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.

Shock and vibration
Don't drop your phone.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Smart practices while driving

Drive safe, call smart

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas — for example, hands-free use only. Go to www.motorola.com/callsmart (in English only) for more information.

Your mobile device lets you communicate by voice and data, almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- Get to know your Motorola mobile device and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
- When available, use a hands-free device. If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original hands-free accessories available today.
- Position your mobile device within easy reach. Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
- Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
- Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility—driving safely.
- Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic. If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.

Disposal of your mobile device packaging & product guide

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Privacy & data security

Motorola

understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device's keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Secure personal information**—Your mobile device can store personal information in various locations including your SIM card, memory card and phone memory. Be sure to remove or clear all personal information before you recycle, return or give away your device. You can also back up your personal data to transfer to a new device.

Note: For information on how to back up or wipe data from your mobile device, go to www.motorola.com/support

- **Online accounts**—Some mobile devices provide a Motorola online account (such as MOTOBUR). Go to your account for information on how to manage the account and how to use security features such as remote wipe and device location (where available).

Location-based information—Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile phones that are connected to a wireless network transmit location-based information. Devices enabled with GPS or AGPS technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, Motorola and other third parties providing services.

Other information your device may transmit—Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to Motorola or other third-party servers. This information is used to help improve products and services offered by Motorola.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Information from the World Health Organisation

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using hands-free devices to keep mobile phones away from your head and body.

Source: WHO fact sheet 193

Further information: <http://www.who.int/peh-emf>

Smart practices while driving

Drive safe, call smart

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas — for example, hands-free use only. Go to www.motorola.com/callsmart (in English only) for more information.

Your mobile device lets you communicate by voice and data, almost anywhere, anytime, wherever wireless service is available and safe conditions